


HUANUO

Monitor Table Stand Instruction Manual

V4.0



Model: HNHM4

Thank you for choosing this HUANUO product! At HUANUO we strive to provide you with the best quality products and services in the industry. Should you have any issues, please don't hesitate to contact us at

Technical Support:

1-800-556-0533 Mon-Fri 8am - 8pm (CST)

Other Info:

support@huanuoav.com (US/CA)

UNPACKING INSTRUCTIONS AND IMPORTANT SAFETY INFORMATION

- Carefully open the carton, remove contents and lay out on cardboard or other protective surface to avoid damage.
- Check package contents against the Supplied Parts and Hardware to assure that all components were received undamaged. Do not use damaged or defective parts.
- Not all parts and hardware included will be used. If you require replacement parts, please contact our Technical Support line at 1-800-556-0533 or customer service at support@huanuoav.com.
- Carefully read all instructions before attempting installation. If you do not understand the instructions or have any concerns or questions, please contact our Technical Support line at 1-800-556-0533 or customer service at support@huanuoav.com.
- This product may contain moving parts. Use with caution.
- Do not use this product for any purpose or in any configuration not explicitly specified in this instruction. We hereby disclaim any liability for injury or damage arising from incorrect assembly, incorrect mounting, or incorrect use of this product.


Supplied Parts and Hardware



01 X1




02 X1



03 X1



04 X1



05 X1



06 X2



07 X2



08 X4



09 X1



10 X1



M8x10mm

A x2



M5x16mm

B x3




C x2



M3x8mm

D x2



1/8 in (3mm)

E x1



15/64 in (6mm)

F x1



M4x12mm
M-A X8



M4X30mm
M-B X8




D4
M-C X8




M-D X8

STEP 1 Connect Upper Pole to Lower Pole


Step 1-1 Loosen the screw [S] on pole [02] using Allen key [E]



Step 1-2 Connect pole [01] to pole [02]




Step 1-2 Tighten the screw [S] using Allen key [E] to fix the two poles




STEP 2A For C Clamp Mounting


Step 2A-1 Install part [03] to pole [02]




Step 1A-2 Adjust the mount according to the thickness of desktop



Step 1A-3 Install part [03] to part [04]




Step 1A-4 Secure the mount to the desktop




STEP 2B For Grommet Mounting


Step 2B-1 Install part [09] to pole [02]



Step 2B-2 Remove part [a] from part [04]



Step 2B-3 Secure the mount to the desktop




Step 3 Install Cable Clips & Monitor Connector to the Pole Assembly

Step 3-1


Slide the two cable clips [07] and the monitor connector [05] to the pole assembly

Step 3-2

Secure the monitor connector [05] to the pole assembly, then attach the cable clips [08] to the monitor connector [05]





Step 4 Check Monitor Hole Pattern and Select Monitor Bolts



75 mm \approx 4 in
100 mm \approx 7 7/8 in

Only one bolt size fits your TV.




Bolt length: Verify adequate thread engagement with bolts or bolts/spacers combination. We recommend thread engagement by at least 5 turns.


- Too short will not hold the monitor.
- Too long will damage the monitor.




Step 5 Attach the Monitor Plates to the Monitors




Step 6 Hang Monitors to the Stand and Secure with Knobs [C] and Bolts [D]




Step 7 Fix Tilt Angle of thr Monitors




Step 8 Manage Cables



Step 9 Store Allen Keys into the Cable Clip






Warning:

To avoid tipping, please be careful not to extend the arms too far forward or backward. When you adjust the angle of the arms, please make sure two arms are balanced to avoid instability of the center of gravity of the base.

Features



Individual VESA plate height adjustment helps monitors to be perfectly aligned.