


# Adjustable Laptop Stand Instruction Manual

V1.0 (B)



# Model: HNLA6



Website: www.huanuoav.com

Thank you for choosing this HUANUO product! At HUANUO we strive to provide you with the best quality products and services in the industry. Please share your experience of our product with others at www.huanuoav.com/reviews if you are satisfied. Should you have any issues, please don't hesitate to contact us at


#### Technical Support:

1-800-556-0533 Mon-Fri 8am - 8pm (PST) (USA) (CAN)


#### Other Info:


support@huanuoav.com (US/CA)

## Supplied Parts and Hardware




Step 1 Loosen the preassembled bolt [B] with Allen Key [A] and keep them for the use of Step 2






**Step 3** Press and hold the button on the joint of the leg then rotate the leg to your desired angle.




Note: Please refer to the procedures in page 4 for more details.

The angles of the two legs must be the same.




Step 5 Secure the edge stoppers to the front lip of the laptop tray.



# How to Use the Cooling Fan

Connect the USB end of the cable to your laptop, then connect the other end of the cable to the port of the cooling fan.


Turn on the switch when use the cooling fan.




#### HOW TO ADJUST THIS LAPTOP STAND AND MAKE IT EASY?

- You only need to adjust the laptop stand legs as shown in the images below.
- To make the adjustment much easier, we provide some popular positions angle setting, please choose the perfect one for your need.

Note: Kindly note that the two legs should be set in the same angle.






# Step ①

- 1. Press button A
- 2. Set angle
- 3. Release

# Step ②


- 1. Press button B
- 2. Set angle
- 3. Release



## Step ③


- 1. Press button C
- 2. Set angle
- 3. Release

# **Popular Positions**




# **Desk Laptop Stand**

- A. 0°
- B. 0°
- C. 15 °




### Sofa Tablet Stand

- A. 30°
- B. 75°
- C. 60 °



## Bed Lap Desk

- A. 90°
- B. 30°
- C. 120 °



## Standing Desk for Work

- A. 90°
- B. 180°
- C. 105 °